

GLOW SHIFTER



INSTALLATION GUIDE

GUIDE INSTALLATION





Open packaging
and remove
contents.

Remove screws
with 2mm allen
key and take out
plastic inserts.





Remove caphead screw with 5mm allen key and seperate two halves of shifter.



Screw on inner core and tighten with 16mm spanner.



Invert shift gaitor



Tighten cable tie around groove to secure shift gaitor



Make sure your shift gaitor is straight. Not like this!




Feed LED wires through the holes in the shift core





Place outer shifter
shape over the core
and LED


Insert clamping disc
with the LED wires
fitting in the slot



Insert and tighten
caphead



Insert LED gripper
into the screw and
fit the LED on top.



Insert light
diffuser disc.



Insert Limit
Break logo disc.




Insert clear top disc.




Tighten screws.

Be careful not to overtighten these on the plastic versions, short end of the allen key is fine.



Connect red cable to 12v auxiliary power (cigarette lighter/stereo etc) and black wire to ground. Be sure there is enough cable leg to allow for the shifter to move.



We include 2x quick splice T tap connectors, feel free to use these although a solder joint is always better!

Rusty I know 🥲



Here is an example from an NB MX-5/Miata. The 12v supply (brown) and earth (black) from the electric window loom is right behind the shifter.

Enjoy your awesome glowing *Limit Break* shifter!!



Contact us if you have any problems. We are happy to help! Email: sales@limitbreakauto.co.uk Discord: <https://discord.gg/RK8EAp4Q> Instagram: www.instagram.com/limitbreakauto/